

Item

To Be Resused - Collected by Whirl

(Cords to remain intact and connected)

Desktop computers - PCs/Apple
Laptops
Remote Controls (batteries removed) (Foxtel remotes to go into recycling bin)
Tablets (iPads and others, including SurfacePros)
Mobile phones
Apple peripherals - any Apple item
iPods
iPod minis
DVD/CD Players
Mixed Peripherals -
Computer games - Nintendo, Wii, Playstation, Xbox, etc
Game Consoles
eReaders - Bulk - Mid Grade
Game Boys
Laptop Chargers
Cameras (all types - film, digital, point n click, etc)
Camera chargers/Battery Chargers - Cannon, Minolta, Pentax,
Camera Accessories - Lenses, flash, lense cleaning kits, filters)
Game Consoles - Refurb - Mid Grade
Xbox
Gameboys
Playstations
Wii
Camera Lens
PC - Gamers
DVD players
Calculators
Video players
Amplifiers
Stereo components
Heritage electronics
PC parts (motherboards)
PC parts - RAM sticks
CPU
Audio / Media Dock
Hard Drives
Telstra TV box
Apple TV box
Yealink landline phones - all parts
TP Link Modems
Plug in Wifi boosters

cords/cables
Branded Laptop chargers (Asus, HP, Toshiba, Lenovo, Compac, Apple)
Servers - blade and box)
Switches
UPS (power source)
Lead Acid batteries
Branded, unopened, unused printer ink cartridges (HP, Cannon, etc)
Routers
Graphics cards
RAM sticks
CPUs
Receivers
Turntables in very good condition
CISCO products
Good quality turntables
Anything unusued and still in a package
Anything you don't know or are unsure of
Anything not on a list leave for us to check
Electric toothbrush chargers
Boomboxes

For Metal Recycling - to be collected by Whirl

All batteries must be removed

Note: cord to be cut and removed

The following items only if the "skin" container is made of metal

Water kettles
Toasters
Heaters
Coffee machines
Hospital equipment with mostly metal
Air conditioners
Pool pumps
Transformers
Vacuum cleaners
Light chargers
Server racks (metal pieces only or boxes holding the servers, not the entire server)
Rack mounts (the metal brackets to hold servers)
Microwaves (if dropped off anyway)

All items

Lamps
non-dyson vacuums
Metal Blender bases only (if it comes with a bowl and non-metal bits put all into SPC bin)
motors
pumps
Irons
Hair dryers

Fans
Ceiling fans (blades removed and kept separately)
Tripods
Corded power tools

To go into the SPC Recycling bins (may be reused to take care)

Note: cords removed and set aside.

No cardboard, plastics or styrofoam

batteries can remain in items

Blenders (plastic base and components together)
Box part of unbranded chargers (cables cut and kept separate)
Coaxial cable (has the pin on the ends)
Drones
Food processors and accessories
Foxtel boxes
Foxtel remotes
Home printers (if dropped off despite saying no)
IP Phones
Landline phones
Low-end or damaged speakers
Low-grade PCBS - i.e power supply boards
Modems - Telco, Huawei, Telstra, Optus, Vodafone, Belong
nything small and plastic and broken - electronic toys
PC Monitors
Plastic blender bases (and all other parts)
Plastic heaters
Portable phones - Uniden handsets etc
Radios
Set-top units (Foxtel boxes etc)
Sound equipment
Teleconference equipment
Damaged, unbranded or cheaply made Turntables
Clock radios
Vapes
Electric toothbrushes
All in one stereos (not boom boxes)

Note: with regards to the bins, in each bin, we also add some of the smaller capacity hard drives (less than 1TB), one old Apple Desktop - the flat screen thick, square ones, an old PC or laptop. Adrian needs to show you. This is to create a more desirable mix for them to make it worth their while to prioritise our pick ups. It becomes more of a win-win. List of items we sprinkle in are listed below. Ask us about this...

motherboards 1-2 per bin
hard drives - 2-3 per bin
very old laptops - 1 per bin
RAM stick - 3-5 per bin
Circuit boards - 1 per bin

PC - 1 per bin

Server - 1 per bin if the mix is particularly plasticity and poor value and we have an extra server)





